

## 1/2" Torque Setting Angular Gauge, int. Square Head (Art. 3084)



- scale: 0-360 °
- stop screw
- incl. L-type wrench

Technical modifications reserved - we are not responsible for issues while printing